


LAON SWINGCRAFT

An aerial photograph of a golf course during the golden hour of sunset or sunrise. The landscape is a mix of green fairways, brownish-yellow roughs, and dense clusters of trees. A winding path or road cuts through the middle of the course. In the lower center, a small clubhouse with a red roof is visible. To the right, there are several interconnected water bodies, including a large pond and smaller streams, reflecting the warm light of the sky. The overall atmosphere is serene and scenic.

VTrack

User Manual

2026. 01.

v1.0.3

A photograph of a golf club head and a golf ball on a green. The club head is silver and the ball is white. The green is lush and green, with a hole visible in the foreground. The background is slightly blurred, showing trees and a clear sky.

INDEX

LAON SWINGCRAFT

01. Setting Guide

02. User Guide


03. Update Guide

1. Setting Guide

- 1) Download
- 2) Extract Folder
- 3) Installation
- 4) Run
- 5) Initial Setup

1. Setting Guide

* For Existing Users




※ If VTrackToolKit 2.0.13 is currently installed, please follow these steps to uninstall it before proceeding with the new installation.

LAON SWINGCRAFT

1. Setting Guide


1) Download



LAON SWINGCRAFT


1. Setting Guide

2) Extract Folder




LAON SWINGCRAFT

1. Setting Guide





2) Extract Folder



1. Setting Guide

2) Extract Folder





1. Setting Guide

5) Initial Setup - Main UI



1. Setting Guide

6) Initial Setup - Network



1. Click on [Device](#) for Network setting
2. Click on [Network List](#)



3. Click on [Connect](#) and wait for the automatic setting
4. Once the Network setup is complete, the [Current Connection](#) is displayed

※ If the Network List is not appeared or Connection is failed, please refer to [Next page](#).

LAON SWINGCRAFT

1. Setting Guide

6) Initial Setup - Fails



1. Cable Issue

Please check that the cable is connected properly

2. Connection fails

The network must be set up manually

Please refer to the "Network Setup Manual_VTrack DX10" for detailed instructions

LAON SWINGCRAFT

1. Setting Guide

6) Initial Setup - Fails





3. Network Setting Fails

1) The network must be checked and configured manually (IP Address, Jumbo Packet/Frame, Receive buffers, and Transmit buffers)
Please refer to the "Network Setup Manual_VTrack DX10" for detailed instructions

2) The antivirus program must be turned off
Please check if the antivirus program is running, and turn it off

1. Setting Guide

7) Initial Setup - Calibration




1. Place the Calibration Board so that the **SCREEN** sign is facing the screen
2. Make sure the Calibration Board is **vertically aligned by eye**
3. Click on **Calibration**

4. Adjust the board's position so the **black box fits inside the yellow box** on the screen
5. Click on **Start**

1. Setting Guide



8) Initial Setup - Ball Check



LAON SWINGCRAFT

1. Setting Guide

9) Initial Setup - Area Setting



READY

Select the area where the actual ball is placed on the left screen

FIXED: setting a specific desired ready area

NON-FIXED: setting the maximum area (indicated by the yellow dotted line)

TEE

Place the green rectangle of the left image on the Tee Area by holding the left mouse button and dragging the mouse

FIXED: setting a specific desired tee area (Only the ball within the green area is recognized as 'Ready' in the driver shot setting)




NON-FIXED: setting the maximum area (All balls within the ready area are recognized as 'Ready')

2. User Guide

- 1) Simulator
- 2) Replay Area Setting
- 3) Shot Information
- 4) Select Data
- 5) Move Data
- 6) User-Defined Data

2. User Guide

1) Simulator




⌘ Before proceeding with this setup, make sure that your desired simulator (such as GSPRO or E6) is already purchased and installed on your PC .

LAON SWINGCRAFT

2. User Guide

2) Replay Area Setting



2. User Guide



3) Shot Information



※ Please change the Hand Type and Club Type for VTrackRange in the Main UI .


2. User Guide

4) Select Data




2. User Guide

4) Select Data



2. User Guide

5) Move Data



2. User Guide

6) User-Defined Data

Flight Path (Side View)

80ft
60ft
40ft
20ft

25yd 50yd

Flight Path (Top)

100yd
75yd
50yd
25yd

-40yd -20yd 0yd 20yd

General

Advanced

Device

Game

Unit

Preset

Detail

	Metric	Imperial	User-Defined
Data	Category	Metric	Imperial
Ball Speed	Ball	m/s	MPH
Launch Angle	Ball	Deg	Deg
Launch Direction	Ball	Deg	Deg
Total Spin	Ball	RPM	RPM
Spin Axis	Ball	Deg	Deg
Back Spin	Ball	RPM	RPM
Side Spin	Ball	RPM (L-R)	RPM (L-R)
Rifle Spin	Ball	RPM	RPM
Club Speed	Club	m/s	MPH
Smash Factor	Club	-	-
Attack Angle	Club	Deg	Deg
Face Angle	Club	Deg	Deg
Club Path	Club	Deg	Deg
Face To Path	Club	Deg	Deg
Impact Horizon	Club	mm	mm

Impact Point (Front View)

Impact Horizontal

Smash Factor

Ball Spin

Back Spin

Spin Axis

0.0

Impact Point (Side View)

Loft

0.0°

Carry

0.0

yd

Total Distance

0.0

yd

Apex

0.0

ft

Launch Angle

0.0

Deg

Face Angle

0.0

Deg

Club Speed

0.0

MPH

Ball Speed

0.0

MPH

Side Spin

0

RPM (L-R)

Back Spin

0

RPM

+

Click on Unit

1

Select the User-Defined

2

Select the MPH or m/s or km/h

3

3. Update Guide

1) Auto Update

3. Update Guide

1) Auto Update

Click on Three vertical dots

2

Update icon appears upon new version release

1

Click on Check Updates

3

Flight Path (Side View)

80ft
60ft
40ft
20ft

25yd 50yd 75yd 100yd

Impact Point (Front View)

Impact Horizontal
0 mm

Smash Factor
0.00

Impact Vertical
0 mm

Ball Spin

Back Spin
0

Side Spin
0

Total Spin
0

Flight Path (Top View)

100yd
75yd
50yd
25yd

-40yd -20yd 0yd 20yd 40yd

Impact Point (Top View)

Face to Path
0.0°

Face Angle
0.0°

Club Path
0.0°

Impact Point (Side View)

Launch Angle
0.0°

Loft
0.0°

Attack Angle
0.0°

Carry
0.0
yd

Total Distance
0.0
yd

Apex
0.0
ft

Launch Angle
0.0
Deg

Face Angle
0.0
Deg

Club Speed
0.0
MPH

Ball Speed
0.0
MPH


Side Spin
0
RPM (L-R)

Back Spin
0
RPM

+

3. Update Guide

1) Auto Update



LAON SWINGCRAFT

Thank You