





SwingEZ Camera Switching



Service team v2026.7.6




1. After selecting the Driving Range or AI Pose Analysis





2. SwingEZ Camera Display Switch



How to Switch Cameras

1. Select the profile at the top right corner
2. Select Setting from the menu
3. Select Camera from the Setting menu
4. Connection -> Click the Switch Cameras "Switch" button

